




ASMB-BMC

ASMB Server Board BMC Function Application for Single Unit

Copyright

The documentation and the software included with this product are copyrighted 2013 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Technical Support and Assistance

1. Visit the Advantech website at <http://support.advantech.com> where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Warnings, Cautions and Notes

Warning! *Warnings indicate conditions, which if not observed, can cause personal injury!*



Caution! *Cautions are included to help you avoid damaging hardware or losing data. e.g.*



There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Note! *Notes provide optional additional information.*



Document Feedback

To assist us in making improvements to this manual, we would welcome comments and constructive criticism. Please send all such - in writing to: support@advantech.com

Safety Instructions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment does not work well, or you cannot get it to work according to the user's manual.
 - The equipment has been dropped and damaged.
 - The equipment has obvious signs of breakage.
15. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -20° C (-4° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.**
16. **CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.**

The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

Safety Precaution - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from your PC chassis before you work on it. Don't touch any components on the CPU card or other cards while the PC is on.
- Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

Contents

Chapter 1	System Requirements	1
1.1	Hardware Requirement	2
1.2	Software Requirement	2
1.3	IPMITool and Other Open Source Software	2
Chapter 2	Setup	3
2.1	HW environment	4
2.2	BIOS Setting	4
2.2.1	BMC Self Test log	5
2.2.2	System Event Log	6
2.2.3	BMC Network Configuration	7
2.3	LAN Setting	7
Chapter 3	Graphics User Interface (GUI)	9
3.1	Login Page	10
3.2	Dashboard	10
3.2.1	Device Information and Network Information	11
3.2.2	Remote Control	11
3.2.3	Sensor Monitoring	11
3.3	Server Health	12
3.3.1	Sensor Readings	12
3.3.2	Event Log	13
3.3.3	System Log	13
3.4	Remote Control	14
3.4.1	Console Redirection	14
3.4.2	Server Power Control	17
3.5	Configuration	18
3.5.1	Active Directory	18
3.5.2	DNS	19
3.5.3	LDAP	20
3.5.4	Local Media	21
3.5.5	Mouse Mode	21
3.5.6	Network	22
3.5.7	NTP	23
3.5.8	PAM Order	24
3.5.9	PEF	24
3.5.10	RADIUS	27
3.5.11	Remote Session	28
3.5.12	Services	29
3.5.13	SMTP	30
3.5.14	System and Audit log	31
3.5.15	Users	32
3.5.16	Virtual Media	33
3.6	Auto Video Recording	34
3.7	Maintenance	35
3.7.1	Firmware update	35
3.7.2	Restore Factory Defaults	36
3.7.3	System Administrator	36
3.8	Log Out	37

Appendix A	Ports Usage	39
-------------------	--------------------------	-----------

Chapter 1

System Requirements

ASMB-BMC functions and specifications mentioned in this document are fully compliant with IPMI 2.0 specification. To set ASMB-BMC on ASMB server boards, the following are required:

1.1 Hardware Requirement

- ASMB server board
- An ASMB-BMC module
- Power Supply
- Keyboard
- LAN cable
- A client computer

1.2 Software Requirement

- IE or other web browsers
- IPMI driver is not required neither on windows nor Linux while ASMB-BMC is with ASMB server board.

1.3 IPMITool and Other Open Source Software

- ASMB-BMC supports open source software IPMITool as long as it is compliant to IPMI2.0

Chapter 2

Setup

2.1 HW environment


To setup ASMB the server board hardware and dedicated LAN for BMC, please refer to ASMB server board user manual.

ASMB-BMC module should be well placed on IPMI1 (2 x 5 pin header), once ASMB-BMC is initialized, an LED indicator will be blinking.

2.2 BIOS Setting

Press or <F2> at bootup to enter AMI BIOS Setup Utility, the Main Menu will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

Server Mgmt is used to modify ASMB-BMC setting.



■ BMC Support

To "Enable or Disable" BMC support. Set BMC support [Disabled] if you don't need BMC function. Once it is disabled, BIOS will not check ASMB-BMC initial status when starting.

■ Wait for BMC

To "Enable or Disable" wait For BMC. Once it is disabled, BIOS will initial without waiting for ASMB-BMC ready.


Note! BMC function will not be active if Wait for BMC is disabled.



- **Wait for BMC Counter**
BMC counter to set waiting time for BMC self test complete, the time for per counter is 5 seconds.

2.2.1 BMC Self Test log

This page is to about the BMC self test Erase Log setting.



2.2.2 System Event Log

To “Enable or Disable” system event log during bootup.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Server Mgmt		
Enabling/Disabling Options		Change this to enable or disable all features of System Event Logging during boot.
SEL Components	[Disabled]	
Erasing Settings		
Erase SEL	[No]	
When SEL is Full	[Do Nothing]	
Custom EFI Logging Options		++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Log EFI Status Codes	[Both]	
NOTE: All values changed here do not take effect until computer is restarted.		


Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.

■ SEL Components

To Enable or Disable system event log (SEL) components.

2.2.3 BMC Network Configuration

BMC network configuration lists LAN configuration such as Address source, IP address, and Subnet mask. The default IP and Subnet mask can be used for first time BMC setting.



There are three types of Address source.

- Unspecified
Use default IP setting.
- Static
Use custom assigned IP setting, set Station IP address and Subnet mask after change Configuration Address to Static.
- Dynamic-Obtained by BMC
Dynamically get IP source from your server board.

Note! LAN2 is available in specific models.



MAC rewrite is only applied in Linux command.

2.3 LAN Setting


If the LAN of the client computer wants to connect to the ASMB server board LAN then the same client and server setting is required to be in the same segment of the IP address of ASMB-BMC on the host.

Chapter 3

Graphical User
Interface (GUI)

To login into the Graphical User Interface (GUI) of ASMB-BMC. Open an Internet browser and connect to the IP address of ASMB-BMC, the login page will show as in the following screen.

3.1 Login Page




Default user name and password

Username	admin
Password	admin

Before starting to use, JAVA is required to be installed to use remote control afterwards.

It is available at <http://www.java.com/en/download/manual.jsp>

3.2 Dashboard



3.2.1 Device Information and Network Information

The left upper area in Dashboard shows general information of the firmware and network settings of your ASMB-BMC module.

3.2.2 Remote Control

The Remote Control screen will show the screen of your monitored server. The screen can be updated manually by clicking the “Refresh” tab.


“Launch” tab will direct the user to the Remote Control function.

3.2.3 Sensor Monitoring

There are green and red status indicators, green means the monitored sensor normal status; otherwise, it is critical when it is red.

There is “HELP” tab on the right upper corner to describe the function of the page.

If new events occur, a notification will pop up, users can click the pop up and see new events.




3.3 Server Health

Server Health shows system temperature and abnormal events.

3.3.1 Sensor Readings

Sensor Readings are at Server Health > Sensor Reading. They provide thresholds and status information of sensors.



Note! To clear Platform alerts, the system has to be reset.




Live widget gives a dynamic representation of the readings for the sensors by clicking ON or OFF to activate the widget.

The live widget will stop updating when time is out. To set timeout, click Configuration > Service from main menu to change web timeout seconds

3.3.2 Event Log

The event log is from Sensor-Specific Event, BIOS Generated, or System Management Software event. The Event ID, Time Stamp, Sensor Type, Sensor Name and Description will be displayed.

Click Server Health > Event log from the main menu to see the logs.



Two Filter Types are available.

- **BMC Timezone**

Displays the BMC UTC Offset timestamp value of the events.


- **Client Timezone**

Displays the events of the Client UTC offset timestamp.

To delete all existing records for all sensors, click “Clear All Event Logs” on the bottom-right.

3.3.3 System Log

Click Server Health > System log to enter the page, and click the System Log tab to view the related events.




Entries can be filtered with levels such as Alerts, Critical Error, Notification, Warning, Debug, Emergency and information.

3.4 Remote Control

Users can use remote control function to connect to the server, and even change the power status of the system. Before launching KVM, it is required to disable any pop-up blocker of your browser.

3.4.1 Console Redirection

The Console Redirection main menu consists of the following menu items.



■ Video

- Pause redirection
To pause Console Redirection.
- Resume Redirection
To resume the Console Redirection when the session is paused.
- Refresh Video
To refresh the display shown in the Console Redirection window.
- Compression Mode
To change Compression with color space.
- DCT Quantization Table
To judge video quality.
- Full Screen
To view Console Redirection in full screen mode. This menu is enabled only when both the client and host resolution are same.
- Exit
To exit the console redirection screen.

■ Keyboard

- Hold Right CTRL Key
To act as the right-side <CTRL> key when in Console Redirection.
- Hold Right Alt Key
To act as the right-side <ALT> key when in Console Redirection.
- Hold Left Ctrl Key
To act as the left-side <CTRL> key when in Console Redirection.
- Hold Left Alt Key
To act as the left-side <ALT> key when in Console Redirection.

- Right Windows Key
To act as the right-side <WIN> key when in Console Redirection. You can also decide how the key should be pressed: Hold Down or Press and Release.
- Left Windows Key
To act as the left-side <WIN> key when in Console Redirection. You can also decide how the key should be pressed: Hold Down or Press and Release.
- Alt+Ctrl+Del
To act as if you depressed the <CTRL>, <ALT> and keys down simultaneously on the server that you are redirecting.
- Context menu
To act as the context menu key in Console Redirection.

■ Mouse


- Show Cursor
To show or hide the local mouse cursor on the remote client system.
- Mouse Calibration
When the mouse mode is disabled. In this step, the mouse threshold setting on the remote server will be discovered.

■ Options

- Bandwidth
To adjust the bandwidth with option “Auto Detect” or alternative bandwidths.
- Keyboard/Mouse Encryption
To encrypt keyboard inputs and mouse movements sent between the connections.
- Zoom
To zoom-in or zoom-out the screen when launching the Java Console.

■ Media

- Virtual Media Wizard
To add or modify a media, select and click “Virtual Media Wizard” button.



- Floppy Key Media1
To start or stop the redirection of a physical floppy drive and the floppy type as img.
- CD/DVD Media1
To start or stop the redirection of an iso file.
- Hard Disc/USB key Media1
To start or stop the redirection of a Hard Disk/USB key image and USB key image such as img.

- Note!**  *For windows clients, if the logical drive of the physical drive is dis-mount then the logical device is redirected with Read/Write Permission else it is redirected with Read permission only.*
- *For MAC client, external USB Hard disk redirection is only supported*
 - *For Linux client, fixed Hard drive is redirected only as Read mode. Write mode is not supported.*
 - *For USB key image redirection, FAT16, FAT32, NTFS are supported.*

■ Keyboard Layout

- Auto Detect
To detect keyboard layout automatically. The languages supported automatically are English - US, French - France, Spanish - Spain, German - Germany, Japanese - Japan.
- Soft Keyboard
To select the keyboard layout.

Note! *Soft keyboard is applicable only for JViewer Application.*



■ Video Record

This option is available only when Java Console is launched. To view this menu option you must download the Java Media Framework (JMF). It can be downloaded from the link <http://www.oracle.com/technetwork/java/javase/download-142937.html>

- Start Recording
To start recording the screen.
- Stop Recording
To stop the recording.
- Settings
To set the settings for video recording.

3.4.2 Server Power Control

This page allows users to view and control the power of the server.

To open Power Control and Status page, click Remote Control > Server Power Control from the main menu.



- **Reset Server**
To reboot the system without powering off (warm boot).
- **Power Off Server - Immediate**
To power off the server immediately.
- **Power Off Server - Orderly Shutdown**
To power off the server immediately.
- **Power On Server**
To power on the server.
- **Power Cycle Server**
To power off first, then reboot the system (cold boot).

3.5 Configuration

Configuration group is for users accessing with various configuration settings.

3.5.1 Active Directory


Active Directory (AD) is a directory service created by Microsoft for Windows domain networks.

Once Active Directory is set, users in the same group will have same privilege as an administrator or a normal user.

To open Active Directory Setting page, click Configuration > Active Directory from the main menu.



The 'Active Directory' is default disabled. To enable Active Directory and configure its settings. Click on the 'Advanced Settings' button.



3.5.2 DNS


The Domain Name System (DNS) is a distributed hierarchical naming system for devices connecting to any network. DNS provides domain names to address participants in the same network.

- **Host Configuration**
 - Host Settings
Manual or Automatic.
 - Host Name
Displays the hostname of the device.
- **Register BMC**
BMC can be registered via direct dynamic DNS or DHCP client FQDN.
- **IPv4 Domain Name Server Configuration**
 - DNS Server Settings
Options for IPv4 DNS settings for the device.
- **IPv6 Domain Name Server Configuration**
 - DNS Server Settings
Options for IPv6 DNS settings for the device.

3.5.3 LDAP

The Lightweight Directory Access Protocol (LDAP) is an application protocol for querying and modifying data of directory services implemented in internet Protocol (IP) networks


Group can be modified after enabling LDAP Authentication in Advanced Setting



- Add Role Group
To add a new role group to the device.
- Modify Role Group
To modify the particular role group.
- Delete Role Group
To delete a role group from the list.


■ Advanced LDAP setting

To configure LDAP Advanced Settings. Options are Enable LDAP Authentication, IP Address, Port and Search base.



3.5.4 Local Media

Local Media shows lists of available images on BMC. Images can be replaced by “Replace Image” or “Delete Image”.



- Note!**
- Only administrator privileges can change local media.
 - Each image type can be uploaded for one image.
 - Maximum upload size is 8 MB.



3.5.5 Mouse Mode

The Redirection Console handles mouse emulation from local window to remote screen.



- **Absolute Mode**
The absolute position of the local mouse will be sent to the server (Recommended when server OS is Windows).
- **Relative Mode**
Calculated relative mouse position will be sent to the server (Recommended when server OS is Linux).

3.5.6 Network

Network settings for available LAN channels.

The screenshot displays the MEGARAC Network Settings page. At the top, there is a navigation bar with tabs: Dashboard, Server Health, Remote Control, Configuration (selected), Auto Video Recording, and Maintenance. The Configuration tab is active, showing the Network Settings section. The page title is 'Network Settings'. Below the title, there is a section 'Manage network settings of the device'. The settings are organized into several sections: LAN Interface (eth0), LAN Settings (Enable checkbox), MAC Address (00:0B:AB:5F:CB:AF), IPv4 Configuration (Obtain an IP address automatically checkbox, IPv4 Address: 192.168.0.1, Subnet Mask: 255.255.255.0, Default Gateway: 0.0.0.0), IPv6 Configuration (IPv6 Settings Enable checkbox, Obtain an IP address automatically checkbox, IPv6 Address, Subnet Prefix length: 64, Default Gateway), and VLAN Configuration (VLAN Settings Enable checkbox, VLAN ID, VLAN Priority). The interface is clean and professional, with a blue header and a white background for the settings area.

- **LAN Interface**
LAN interface list.
- **LAN Settings**
LAN settings can be enabled or disabled.
- **MAC Address**
The field displays the MAC Address of the device. It is read only.
- **IPv4 setting**
This option lists the IPv4 configuration settings.
 - Obtain IP Address automatically
This option dynamically configures an IPv4 address using DHCP.
 - IPv4 Address, Subnet Mask, and Default Gateway
These fields are for specifying the static IPv4 address, Subnet Mask and default gateway to be configured to the device.
- **IPv6 setting**
This option lists the IPv6 configuration settings.
 - IPv6 Settings
This option enables the IPv6 settings in the device.
 - Obtain IPv6 Address automatically
This option dynamically configures an IPv6 address using DHCP.
 - IPv6 Address
To specify a static IPv6 address to be configured to the device.
 - Subnet Prefix length
To specify the subnet prefix length for the IPv6 settings (Value ranges from 0 to 128).
 - Default Gateway
Specify the default gateway for the IPv6 settings.
 - VLAN Configuration
It lists the VLAN configuration settings.
- **VLAN Settings**
To enable/disable the VLAN support for selected interface.
 - VLAN ID
The identification for VLAN configuration (Value ranges from 1 to 4095).

- VLAN Priority
The priority for VLAN configuration (Value range from 1 to 7, 7 is the highest priority for VLAN).

3.5.7 NTP

The Network Time Protocol (NTP) is protocol for synchronizing the clocks of computer systems over packet-switched, variable-latency data networks. NTP is default disabled.

NTP Setting pages at Configuration > NTP from the main menu.

MEGARAC American Megatrends

Dashboard Server Health Remote Control Configuration Auto Video Recording Maintenance

admin/Administrator Refresh Print Logout HELP

NTP Settings

Here you can either configure the NTP server or view and modify the device's Date & Time settings.

Date: June 19 2013

Time: 17:02:17 (hh:mm:ss)

UTC Timezone: (GMT+/-) Hours(s)

NTP Server: pool.ntp.org

☒ Automatically synchronize Date & Time with NTP Server

Refresh Save Reset

- **Date**
The current date for the device specifically.
- **Time**
The current time for the device specifically.
- **UTC Timezone**
To display the local time, choose the UTC timezone values in the listed box.
- **NTP Server**
The NTP server for the device specifically.
- **Automatically synchronize**
The date and time will be automatically synchronized with the NTP server if checking the box.

3.5.8 PAM Order

Pluggable Authentication Module (PAM) Ordering provides the priority list of available PAM module for user authentication to the BMC. The authentication will be verified in order. To disable one of the authentication, go to the dedicate page to disable it.

PAM Ordering at Configuration > PAM Order from the main menu.




3.5.9 PEF

Platform Event Filtering (PEF) provides a regular mechanism for configuring the BMC to take selected actions on event messages that it receives or has internally generated. These actions include operations such as system power-off, system reset, as well as triggering the generation of an alert.

To open PEF Management Settings page, click Configuration > PEF from the main menu

■ Event Filter Tab

Choose the Event Filter, double click or click Modify tab to modify Event Filter, or click the blank Event Filter to add new setting.



– PEF ID

This field displays the ID for the newly configured read-only PEF entry.

- Filter configuration
Check box to modify the PEF settings.
- Event Filter Action
Check box to modify PEF Alert action.
- Event Severity
To choose any one of the Event severity from the list.
- Sensor Name
To choose the particular sensor from the sensor list.

■ Alert Policy Tab

This page is used to configure the Alert Policy and LAN destination. Entries can be added, deleted or modified in this page.

Choose the Policy Entry, double click or click Modify tab to modify Alert Policy Entry, or click the blank Policy Entry to add new setting.

- Policy Entry #
Displays Policy entry number for the newly read-only configured entry.
- Policy Number
Displays the Policy number of the configuration.
- Policy Configuration
To enable or disable the policy settings.

- Policy Set
To choose any one of the Policy set values from the list.
 0. Always send alert to this destination
 1. If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set.
 2. If alert to previous destination was successful, do not send alert to this destination. Do not process any more entries in this policy set.
 3. If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set that is to a different channel.
 4. If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set that is to a different destination type.
- Channel Number
To choose a particular channel from the available channel list.
- Destination Selector
To choose a particular destination from the configured destination list.

■ LAN Destination

To add, delete or modify LAN destination.

Choose the LAN Destination, double click or click Modify tab to modify LAN Destination, or click the blank LAN Destination to add new setting.

The screenshot shows the MEGARAC PEF Management interface. At the top, there's a navigation bar with tabs: Dashboard, Server Health, Remote Control, Configuration (selected), Auto Video Recording, and Maintenance. Below this, the 'PEF Management' section is active, with sub-tabs: Event Filter, Alert Policy, and LAN Destination (selected). A dropdown menu for 'LAN Channel' is set to '1'. A table with 15 rows and 3 columns (LAN Destination, Destination Type, Destination Address) is displayed. All cells in the table are empty. At the bottom right, there are buttons: 'Send Test Alert', 'Add', 'Modify', and 'Delete'.

LAN Destination	Destination Type	Destination Address
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		

MEGARAC American Megatrends

Dashboard Server Health Remote Control Configuration Auto Video Recording Maintenance

admin Administrator Refresh Print Logout HELP

PEF Management

Use this page to configure Event Filter, Alert Policy and LAN Destination. To delete or modify a entry, select it in the list and press "Delete" or "Modify". To add a new entry, select an unconfigured slot and press "Add".

Event Filter

LAN Channel: 1

LAN Destination count: 9

Add LAN Destination entry

LAN Channel Number: 1

LAN Destination: 1

Destination Type: SNMP Trap

Destination Address:

Username: anonymous

Subject:

Message:

Add Cancel

Send Test Alert Add Modify Delete

- LAN Destination
Display Destination number for the newly configured read-only entry.
- Destination Type
To select SNMP Trap or an Email alert. The SMTP server information also has to be added-under Configuration > SMTP.
- Destination Address
Destination address supports IPv4 address format and IPv6 address format.
- Subject & Message
These fields must be configured if email alert is chosen as destination type.

3.5.10 RADIUS

To "enable or disable" RADIUS, check or uncheck the "RADIUS Authentication" Enable checkbox.

MEGARAC American Megatrends

Dashboard Server Health Remote Control Configuration Auto Video Recording Maintenance

admin Administrator Refresh Print Logout HELP

RADIUS Settings

Check the box below to enable RADIUS authentication and enter the required information to access the RADIUS server. Press the Save button to save your changes.

RADIUS Authentication ☒ Enable

Port: 1812

Time Out: 3 seconds

Server Address:

Secret:

Save Reset

- **RADIUS Authentication**
Option to enable RADIUS authentication. User can click “HELP” to see the detail setting for each column.
- **Port**
The RADIUS Port number.
- **Time Out**
The Time out value in seconds, the range is from 3 to 300.
- **Server Address**
The IP address of RADIUS server.
- **Secret**
The Authentication Secret for DADIUS server.


3.5.11 Remote Session

This page is for users to configure virtual media configuration settings for the redirection session. The default is encryption disabled.

- **KVM Encryption**
Enable or Disable encryption on KVM data for the next redirection session.
- **Media Encryption**
Enable or Disable encryption on Media data for the next redirection session.
- **Virtual Media Attach Mode**
Two types of VM attach mode are available.
 - Attach
Immediately attached Virtual Media to the server upon boot-up.
 - Auto
Attaches Virtual Media to the server only when a virtual media session is started.

3.5.12 Services

This page is used to display the services running in the BMC. To modify a service, the user must be an Administrator.



MEGARAC American Megatrends

Dashboard Server Health Remote Control Configuration Auto Video Recording Maintenance

admin/Administrator Refresh Priv Logout HELP


Services

Below is a list of services running on the BMC. It shows current status and other basic information about the services. Select a slot and press "Modify" button to modify the services configuration.

Number of Services: 7

#	Service Name	Current State	Interfaces	Nonsecure Port	Secure Port	Timeout	Maximum Sessions
1	web	Active	eth0	80	443	1800	20
2	ivm	Active	eth0	7578	7582	-	2
3	cd-media	Active	eth0	5120	5124	-	1
4	fd-media	Active	eth0	5122	5126	-	1
5	hd-media	Active	eth0	5123	5127	-	1

Modify



MEGARAC American Megatrends

Dashboard Server Health Remote Control Configuration Auto Video Recording Maintenance

admin/Administrator Refresh Priv Logout HELP

Services

Below is a list of services running on the BMC. It shows current status and other basic information about the services. Select a slot and press "Modify" button to modify the services configuration.

Number of Services: 7

#	Service Name	Current State	Interfaces	Nonsecure Port	Secure Port	Timeout	Maximum Sessions
1	web	Active	eth0	80	443	1800	20
2	ivm	Active	eth0	7578	7582	-	2
3	cd-media	Active	eth0	5120	5124	-	1
4	fd-media	Active	eth0	5122	5126	-	1
5	hd-media	Active	eth0	5123	5127	-	1

Modify

Modify Service

Service Name: web

Current State: ☒ Active

Interfaces: eth0

Nonsecure Port: 80

Secure Port: 443

Timeout: 1800 seconds

Maximum Sessions: 20

Modify Cancel


- **Service Name**
Displays service name of the selected slot (read-only).
- **Current State**
Display the current status of the service, either active or inactive.
- **Interfaces**
Shows in the interface which service is running.
- **Nonsecure Port**
This port is used to configure the non secure default port number for the service. Click "HELP" to see port occupation for application.
- **Secure Port**
Used to configure secure default port number for the service. Click "HELP" to see port occupation for application.
- **Timeout**
Display the session timeout value of the service.
- **Web timeout value range**
Web timeout value range: 300 to 1800 seconds.

- **Maximum Sessions**

Displays the maximum number of allowed sessions for the service.

3.5.13 SMTP

Email notification alerts will be sent while SMTP (Simple Mail Transfer Protocol) is set. This function helps the administrator to be notified when the status of the server changes.



- **LAN Channel Number**

Display the list of LAN channels available.

- **Sender Address**

The “Sender Address” valid on the SMTP Service.

- **Machine Name**

The “Machine Name” of the SMTP Service. Naming criterion please see “HELP”.

- **Primary SMTP Service**

Lists the Primary SMTP Server configuration.

- Server Address

The “IP address” of the SMTP Server.

- SMTP Service requires Authentication

To enable/disable SMTP Authentication, supports CRAM-MD5, LOGIN, and PLAIN.

- Username

The username to access SMTP Accounts. Username criterion is listed in “HELP”.

- Password

The password for the SMTP User Account. Username criterion is listed in “HELP”.

- **Secondary SMTP Server**

Lists the Secondary SMTP Server configuration. It is an optional field. If the Primary SMTP server is not working fine, then it tries with Secondary SMTP Server configuration.

3.5.14 System and Audit log

System and Audit log page displays a list of system logs and audit logs occurred in this monitored server.

To open System and Audit log page, click Configuration > System and Audit Log from the main menu.

- **System Log**
This field is to enable or disable the system logs.
- **Log Type**
Specifies the Log type for system logs, whether it should be preserved in a local file or on a remote server.

Note! Local file resides at/var/log/.



- **File Size**
To specify the size of the file in bytes if the selected log type is local. Size ranges from 3 to 65536.
- **Rotate Count**
When logged information exceeds the specified file size, the old log information automatically gets moved to back up files based on the rotate count value. If the rotate count is zero, the old log information gets cleared permanently each time. Value ranges from 0 to 255.
- **Server Address**
To specify the remote server address to the log system events. Server Address supports IPv4 and FQDN format.
- **Audit Log**
To enable or disable the audit log.

3.5.15 Users

The user management page allows users to view the current list of user slots for the server. User can be added, modified, or deleted.

To open User Management, click Configuration > Users from the main menu.

UserID	Username	User Access	Network Privilege	SNMP Status	Email ID
1	anonymous	Disabled	User	Disabled	-
2	admin	Enabled	Administrator	Disabled	-
3	-	-	-	-	-
4	-	-	-	-	-
5	-	-	-	-	-
6	-	-	-	-	-
7	-	-	-	-	-
8	-	-	-	-	-
9	-	-	-	-	-
10	-	-	-	-	-

- **User ID**
Displays the ID number of the user (maximum of ten users).
- **User Name**
Displays the name of the user.
- **User Access**
To enable or disable the access privilege of the user.
- **Network Privilege**
Displays the network access privilege of the user.
- **SNMP Status**
Displays email address of the user.

To modify or add users by selecting a configured slot or a free slot. Click “HELP” to see the criterion for each column about user privilege and setting.

Modify User

Username: anonymous

☒ Confirm Password

Password Size: ☒ 16 Bytes ☐ 20 Bytes

Password: [Empty]

Confirm Password: [Empty]

User Access: ☒ Enable ☐ Disable

Network Privilege: User

SNMP Status: ☒ Enable ☐ Disable

Authentication Protocol: SHA

Privacy Protocol: DES

Email ID: [Empty]

Email Format: AMI Format

Modify Cancel

HELP

Use this form to modify the existing user's password and permission.

ACTIONS

User Name
The name of the user being configured (read only).

Confirm Password
To change the user's password, check the "Confirm Password" option. This will enable the password fields.

Password Size
Either 16 Bytes or 20 Bytes password size can be chosen. Default option is 16 Bytes. If "16 Bytes" option is chosen, maximum password size is 16 characters. If "20 Bytes" option is chosen, maximum password size is 20 characters. **NOTE:** For 20 Bytes password, tan session will not be established.

Password, Confirm Password
Enter and confirm the new password here.
- Password must be at least 1 character long.
- White space is not allowed.
NOTE: This field will not allow more than 16/20 characters based on Password size field value.

User Access
Check the box to enable user access for the user.

Network Privilege
Select the level of network privilege to be assigned to this user. 4 levels are available: Administrator, Operator, User and No Access.

SNMP Status
Check the box to enable SNMP access for the user.

3.5.16 Virtual Media

This page is to configure Virtual Media device settings.

To open Virtual Media page, click Configuration > Virtual Media from the main menu.

- **Floppy devices**
Selects the number of floppy devices that support for Virtual Media redirection.
- **CD/DVD devices**
Selects the number of CD/DVD devices that support for Virtual Media redirection.
- **Harddisk devices**
Selects the number of hard disk devices that support for Virtual Media redirection.
- **Local Media Support**
To enable or disable the local media support for Virtual Media redirection.

3.6 Auto Video Recording

The Auto Video Recording consists of Triggers Configuration and Recorded Video. To set configure triggers for various events, click Auto Recording > Triggers Configuration from the main menu.

The screenshot shows the MEGARAC web interface. The top navigation bar includes 'Dashboard', 'Server Health', 'Remote Control', 'Configuration', 'Auto Video Recording', and 'Maintenance'. The 'Auto Video Recording' sub-menu is open, showing 'Triggers Configuration' and 'Recorded Video'. The 'Triggers Configuration' page has a header explaining its purpose: 'This page allows the user to configure which events will trigger the auto video recording function of the KVM server'. It features two columns of checkboxes for event triggers. The left column includes: 'Temperature/Voltage Critical Events', 'Temperature/Voltage Non Recoverable Events', 'Watchdog Timer Events', 'Chassis Power off Event', and 'Particular Date and Time Event'. The right column includes: 'Temperature/Voltage Non Critical Events', 'Fan state changed Events', 'Chassis Power on Event', 'Chassis Reset Event', and 'LPC Reset Event'. Below the left column, there are input fields for 'Date' (Month: January, Day: 1, Year: 2005) and 'Time' (hh:mm:ss: 00:00:00). At the bottom right, there are 'Save' and 'Reset' buttons.

To open Video recording page, click Auto Video Recording > Recorded Video from the main menu.

The screenshot shows the 'Video Recording' page in the MEGARAC web interface. It includes a header with the same navigation bar as the previous page. Below the header, a text block explains: 'Below is a list of available recorded video files on the BMC. Select a video and press the "Play Video" button to play the video. Select a video and press the "Download" button to download and save the video. Press the "Delete" button to delete the selected video.' A table lists the available video files. The table has three columns: '#', 'File Name', and 'File Information'. There is one row of data. Below the table, there are 'Play Video', 'Download', and 'Delete' buttons.

#	File Name	File Information
1	video_dump_0.dat	Wed Jun 19 17:51:20 2013

- **#**
The serial number.
- **File Name**
The video filename.
- **File Information**
Day, date and time of video upload.
- **Play Video**
To play the selected video.
- **Download**
To download the elected video.

■ Delete

To delete the selected video.

Note!



- A maximum of only 2 video files can be recorded and available for access, with each recording limited to 5.5MB or 20 seconds whichever is earlier.
- Further event occurrences will be ignored and no recording will happen, until at least one video file is deleted.
- If the recorded video files are stored in RAM, then those video recordings will not be persistent upon BMC reboot.

3.7 Maintenance


Maintenance for back end management.

3.7.1 Firmware update

An easy firmware update method for users, cancelation is available during the step-by-step process.

Click the Enter Update Mode tab and follow the instruction.

To open Firmware Update page, click Maintenance > Firmware Update from the main menu



Note!



- After entering “update mode widgets”, other web pages and services will not work. All open widgets will be closed automatically. If the upgrade process is cancelled in the middle of the wizard, the device will be reset. The browser has to be closed and the user has to log back onto the Internet again before performing any other types of operations.
- Please make sure the chances of a power or connectivity loss are minimal when performing firmware upgrades.


3.7.2 Restore Factory Defaults

This option is used to restore the factory defaults of the device firmware. The system will reboot automatically.

Note! *After entering restore factory widgets, other web pages and services will not work. All open widgets will be closed automatically. The device will reset and reboot within few minutes.*




To open Restore Factory Defaults page, click Maintenance > Restore Factory Defaults from the main menu.



3.7.3 System Administrator

System Administrator page allows a user to change passwords.




- **Username**
Username of System Administrator is a read only field.
- **User Access**
To enable user access for system administrator.

■ Password

To change the user's password. The password must be at least 8 characters long, and white spaces are not allowed.

3.8 Log Out

To log out, click the logout link on the top right corner of the screen.



Appendix **A**

Ports Usage

Port #	Owner Module	Usage
80	Web server	Listening for network connections on HTTP://
443	Web server	Listening for secured network connections on HTTP://
5120	CD media server	To accept regular CD media redirection connections
5123	Floppy media server	To accept regular HD media redirection connections
5122	HD media server	To accept regular FD media redirection connections
7578	KVM server (adviser)	To accept regular KVM redirection connections
623	IPMI	LAN interface
1900	uPnP discovery	Used for uPnP based BMC discovery
50000	uPnP discovery	Used for uPnP based BMC discovery
555	WSMAN	Eventing daemon's listening port (Implemented, not enabled)
5988	SFCB(WSMAN)	WSMAN related
427	SLPD	Service Loater



Enabling an Intelligent Planet

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2013

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Advantech:](#)

[ASMB-BMC-00A1E](#)