



Copyright (C) 2005, OLIPHANT LTD  
http://www.oliphant.com/dev

## STR-H711 BOARD HEADER ASSIGNMENTS

EXT1			EXT2		
P0.1	1	0	P0.0	GND	38 39 nRST
P0.3	3	2	P0.2	5V-USB	36 37 3.3V
P0.5	5	4	P0.4	BOOTEN	34 35 STB
P0.7	7	6	P0.6	V1.8BKP	32 33 1.8V
P0.9	9	8	P0.8	P1.14	30 31 P1.15
P0.11	11	10	P0.10	DN	28 29 CLK
P0.13	13	12	P0.12	P1.10	26 27 DP
P0.15	15	14	P0.14	P1.8	24 25 P1.9
P1.1	17	16	P1.0	P1.6	22 23 P1.7
P1.3	19	18	P1.2	P1.4	20 21 P1.5

The pin numbers are printed on the top silkscreen, the above drawings are with TOP view of the board

The distance between the headers is 1"

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Olimex Ltd.:](#)

[STR-H711](#)