

- 2 2 2 2 2168083-1 SCR, SKT HD CAP, RoHS, M3 X 8.0 269
-77 -27 -25 -22 -21 PART NO DESCRIPTION ITEM NO

PACIFIC VERSION
Shown on sheets 3 of 4 & 4 of 4
(Atlantic version shown on sheets 1 of 4 & 2 of 4)

		SET 211	UP GA 9599 		А	6 6 P LTR		DWN APVC
						- SEE S	HEET 1 -	
	-	1	1	1	1	1633782-2	FENCE	267
	-	1	1 _	1	1 -	2119782-1	FINE ADJUST HEAD ASM, PACIFIC STYLE PUSH ROD, AIR FEED	251 250
	-	-	-	1	-	2079988-1	BUSHING, LCH5-12, MISUMI	249
	-	1	1	1	1	1-22279-3	SPRING, COMPRESSION	246
	-	1	1	1	1	2119082-4	CAM, SNAIL, INSULATION ADJUSTMENT WASHER, WAVE SPRING, CREST-TO-CREST	1 2 4 2 T 1 2 4 3
6	-	1	1	1	1	2119083-1	RETAINER, INSULATION DIAL	242
-	-	1	1	1	1	7-18023-7	SCR, SKT HD CAP M3 X 4.0	241
	-	-	2	-	1	2168400-6 2119580-1	SHCS, LOW HEAD, ROHS, M5 X 16 MECHANICAL FEED ASSEMBLY	240
-	-	-	-	1	-	2063440-1	AIR FEED MODULE	238
-	-	-	1	-	-	2119740-2	TAG, IDENTIFICATION	213
	-	-	-	2	-	1901094-3	SPACER, FEEDER RING, RETAIN, EXTERN, 3/16 CRESCEN	198 T172
	-	1	1	1	1	994969-1	MAGNET, RARE EARTH HIGH ENERGY	166
-	-	REF	REF	REF 1	REF	994970-2	COUNTER, MAGNETIC SPRING, FEED FINGER	162
	-	1	1	1	1		O-RING, .801 ID, .070 DIA. MAT.	152
	-	-	-	1	-	2119641-2	FEED CAM, AIR FEED	151
	-	1	1 1	1 1	1	2119798-2 2079383-8	DETENT PIN SCR, BHSC, RoHS (M4 X 16)	145
	-	4	4	4	4	2168400-5	SHCS, LOW HEAD, RoHS, M4 X 20	143
	-	1	1	1	1 1		FEED CAM, POST FEED  APPLICATOR BASIC ASSEMBLY, SF	142
	_	1	1	1	1	2119650-1	RAM, ASIAN STYLE, SIDE FEED	140
	-	1	1	1	1		BOLT, ADJUSTMENT	139
	-	-	-	1	-		PIN, RETAIN, GRVD, 3/16 X .854 HOLDER, FEED FINGER, AF	137
	-	-	REF	-	-		MEMORY CHIP, PROGRAMMED	135
	-	-	1 REF	-	-		SERVO FEED LATCH ASM FEED FINGER ASSEMBLY, SF	133
	_	1	1	1	1		SPACER, CRIMPER	82
	-	1	1	1	1	2119956-1	DOCUMENTATION PACKAGE	71
	-	1	1 -	1 1	1 1	2119791-5	DEPRESSOR, WIRE TAG, IDENTIFICATION	70
	_	2	2	2	2		SCREW, DRIVE, RH, RoHS, 2 x .188	66
	-	3	3	3	3		LIMITER, ADJUSTMENT BOLT	63
6	_	-	-	1	1	992763-5 5-18022-5	SCR, SET, SOC, CONE POINT, M3 x 4.0 SCR, HEX HD CAP, M4 X 6.0	62
	-	-	-	1	1	1338685-1	PAWL, FEED	56
	-	2	2	2	2	2168083-8 5018030-1	SCR, SKT HD CAP, RoHS, M4 X 16 NUT, HEX, REG, RoHS, M3	53
	-	1	1	1	1	811242-5	BUMPER, HOLD DOWN	51
	-	1 _	1 -	1	2	690753-2 18023-9	SPACER, TONKER SCR, SKT HD CAP M4 X 6.0	50
	_	-	-	-	1	2119652-1	FEED CAM, PRE FEED	4 3
	-	1	1	1	1	2079383-7	SCR, BHSC, RoHS (M8 X 25)	41
	-	1	1	1	1	2119645-1	DISC, NUMBERED FA WIRE ADJUSTMENT APPLICATOR SHIM PACK	40
	-	1	1	1	1		RAM WASHER, PRECISION	38
	-	2	2	2	2	1752356-1 2079383-5	SUPPORT, TERMINAL SCR, BHSC, RoHS (M4 X 20)	34
	-	1	1	1	1		HEX HEAD, FLANGED, M5 x 8mm LONG	32
	-	1	1	1	1		SPACER, STRIP GUIDE	30
	-	1	1 1	1 1	1	2119959-1	ASSEMBLY, STRIP GUIDE STRIP GUIDE	29
	-	1	1	1	1	2168083-2	SCR, SKT HD CAP, RoHS, M4 X 8.0	21
	-	2	2	2	2		WASHER, FLAT, REG M4 STRIPPER, SIDE FEED	20
	-	1	1	1	1	2119333-1	INSERT, SHEAR	13
	-	1	1	1	1	3-22280-3	SPRING, COMPRESSION	12
$\bigwedge$	-	1	1 1	1 1	1 1	1 - 356885 - 4 2119805 - 1	STOP, SHEAR SHEAR HOLDER, FRONT	1 1 0
1	-	1	1	1	1	1803095-3	FLOATING SHEAR, FRONT	9
/1	1	1	1	1	1	9-1803171-4	ANVIL, COMBINATION	8
	-	-	-	-	-	240041-3	SPACER -	6
	-	1	1	1	1	1-2119757-0	DEPRESSOR, SHEAR	5
$\bigwedge$	- 1	1	1 1	1 1	1 1	238011-8 7-1633966-8	BLOCK, CRIMPER SPACER CRIMPER, INSULATION O	4 3
,	-	1	1	1	1	455888-6	SPACER, CRIMPER	. 2
/1\	1	1	1	1	1	7-1633588-8	CRIMPER, WIRE	1
No.	- 7 7		- 25			PART NO	DESCRIPTION	I T E M
NG IS A SJECT TO SHOUL	CONTROLLED CHANGE AND D BE CONTAC	DOCUMENT F THE CONTRO CTED FOR TH	OR TYCO ELEC LLING ENGINE E LATEST REV	IRONICS COR ERING ORGAN VISION.	-	DWN 31MAR2016 BOB HIGMAN CHK 31MAR2016	TE Connectivity Harrisburg, PA 17105-3608	
MENSIO	NS:		TOLERAN OTHERWISI	ICES UNLE E SPECIF		G.BAILEY  APVD 31MAR2016 G.BAILEY	NAME Ocean Side Feed	
mm		0 P	LC :	±- ±-		PRODUCT SPEC	Applicator	
(4)			LC :	±- ±- ±-	-	APPLICATION SPEC	SIZE CAGE CODE DRAWING NO	STRICTED T
$\Psi$		4 P	LC : LES	_	I	-	SIZE CAGE CODE DRAWING NO	COUNTRIED

AMP 4805 REV 31MAR2000

MAGNET MUST BE ORIENTED CORRECTLY IN ORDER TO PROPERLY

NECESSARY WHEN RUNNING APPLICATOR IN THE FIELD.

CRIMP HEIGHT REFERENCE SETTING WAS THE SETTING USED WHEN THE APPLICATOR WAS QUALIFIED AT THE FACTORY. ADJUSTMENT MAY BE

SPARE FEED CAM STORAGE LOCATION REFER TO INSTRUCTION SHEET


11 TO CONVERT THE APPLICATOR TO A NON-CARRIER CUTTING STYLE,

REMOVE ITEM 13 AND ATTACH TO THE LOCATION ON BACK SIDE OF THE HOUSING. REFER TO INSTRUCTION SHEET FOR ADDITIONAL

ACTUATE THE COUNTER.

INFORMATION.

FOR ADDITIONAL INFORMATION.



## **Mouser Electronics**

**Authorized Distributor** 

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

TE Connectivity: 2151897-2